

# VOODOO PRO

## LED Codes

### LED 1

*Power and Fault Codes*

BLUE

RED

ECU Hold Power Active

No connection to comms board

(ECU Fault Codes – Flashing codes using the color above)

### LED 2

*Wi-Fi and Bluetooth*

OFF

FLASHING GREEN

SOLID GREEN

FLASHING BLUE

SOLID BLUE

SOLID WHITE

Wi-Fi Turned off

Wi-Fi in AP Mode

Wi-Fi in AP Mode with client connected

Wi-Fi in Client Mode

Wi-Fi in Client Mode connect to Wi-Fi

Client connected over UDP

### LED 3

*Logging/GPS Status*

	<i>GPS Off</i>	<i>GPS Enabled</i>	<i>GPS Locked</i>	<i>GPS Error</i>
<i>ECU Logging Off</i>	LED Off	Flashing Blue	Solid Blue	Flash Purple
<i>ECU Logging Armed</i>	Flashing Green	Flashing White	Alternating Blue/White	Flashing Purple
<i>ECU Logging Running</i>	Solid Green	Alternating Green/White	Solid White	Flashing Purple
<i>ECU Logging Error</i>	Flashing Yellow	Flashing Yellow	Flashing Yellow	Flashing Red